


Programming Instructions

To Set or Change the Day and Time:

To clear entire memory, press  key. Hold down the **CLOCK** key while pressing either the **DAY**, **HOURL** or **MINUTES** keys. Continue pressing until the desired day or number is shown. Then simply lift finger off of the **CLOCK** key to set.

To Set Program (ON/OFF times):

Press **TIMER** key once to enter into program mode. Display will show “1 ON - - - -”. Press **DAY** key to choose any of 15 different day combinations for the first **ON** time. *Note: days of the week having the same program should be copied by selecting the desired combination of days.*

Press the **HOURL** key and then the **MINUTE** key to select the desired first **ON** time.

Press **TIMER** key once. Display will show “1 OFF - - - -”. Repeat previous step to select the desired **OFF** time. Repeat the entire sequence to complete up to eight **ON/OFF** times as desired.

When programming is done, press the **CLOCK** key then the **MANUAL** key repeatedly until the indicator bar is above the word “**AUTO**”

To Review Program:

Press **TIMER** key repeatedly. When done, press **CLOCK** key to return to the time of day.

To Cancel/Change Part of the Program:

Press **TIMER** key repeatedly until the particular **ON** or **OFF** time appears, the repeatedly press the **DAY** key until the display show “ - - - -”. Set new **ON** and **OFF** time.
(See: To Set Programs)

To Override Automatic Operation:

Press **MAMUAL** key to move indicator bar to the desired **ON** or **OFF** position.
*Note: Timer will not resume automatic operation until indicator bar is repositioned above the word **AUTO**.*

